

## **Preparation of Tissue for Scanning Electron Microscopy**

1. Fix tissue in 2.5% glutaraldehyde in 0.1M sodium cacodylate buffer pH 7.3 with 3mM  $\text{CaCl}_2$ .
2. Rinse 0.1M cacodylate buffer
3. Fix in 1%  $\text{OsO}_4$