Preparation of Tissue for Scanning Electron Microscopy

- 1. Fix tissue in 2.5% glutaral dehyde in 0.1M sodium cacodylate buffer pH 7.3 with 3mM \mbox{CaCl}_2 .
- 2. Rinse 0.1M cacodylate buffer
- 3. Fix in 1% OsO₄